

Das **Dynamic Configuration Protocol** (DCP) hat die Aufgabe, die Adressen und Namen in einem PROFINET IO System den einzelnen Teilnehmern zu verteilen.

Das DCP Protokoll ist in der Norm IEC 61158 festgelegt.

Sequenzen von Telegrammen und die Dienste werden im Abschnitt der Adressverwaltung erläutert.

Die DCP Telegramme hat den Ethernet TYPE 0x8892 = PROFINET und die folgende Struktur:

DCP Telegramm	Umfang	Werte	Bedeutung
FrameID	2 Byte	0xfefd - 0xfeff	Reservierter Bereich für das DCP
ServiceID	1 Byte	1 = Get 2 = Set 5 = Identify	
Service-Type	1 Byte		
xid	4 Bytes		Identifikation der Transaktion
ResponseDelay	2 Bytes		
DCPDataLength	2 Bytes		Anzahl der Bytes in den nachfolgenden Blöcken
Block	x Bytes		

Ein DCP Telegramm kann bei Wireshark so aussehen:

```

❑ PROFINET acyclic Real-Time, ID:0xfefe, Len: 24
  FrameID: 0xfefe (Real-Time: DCP (Dynamic Configuration Protocol) identify multicast request)
❑ PROFINET DCP, Ident Req, Xid:0x8011, NameofStation
  Service-ID: Identify (5)
  Service-Type: Request (0)
  xid: 0x00008011
  ResponseDelay: 1
  DCPDataLength: 14
  ▣ Block: Device/NameofStation, "ilb-pn-dio"

```

Der **Service-Type** wird wie folgt kodiert:

7	6	5	4	3	2	1	0	Service-Type
0	0	0	0	0				
					x			0 = success (Erfolgreich)
						x	x	0 = Request (Anforderung)
								1 = Response (Antwort)

Jeder **Block** in einem DCP Telegramm beschreibt nun spezielle Eigenschaften:

Option	Suboption	len	Status	Data
1 Byte	1 Byte	2 Bytes	2 Bytes	len Bytes
1	1 = MAC Address	6		
	2 = IP Address	14		
2	1 = Manufacturer Specific			
	2 = Name of Station			
	3 = Device ID			
	4 = Device	4		
	5 = Device options	1		
3	All DHCP options			
4	LLDP options			
5	1 = Start Transaction	0		
	2 = End Transaction	0		

Ein DCP-Block zum setzen einer IP Adresse kann bei Wireshark so aussehen:

```

Block: IP/IP, Status: IP set, IP: 147.87.174.145, Subnet: 255.255.254.0, Router: 147.87.175.16
  option: IP (1)
    Suboption: IP parameter (2)
    DataBlockLength: 14
    Status: IP set (1)
    IPaddress: 147.87.174.145 (147.87.174.145)
    Subnetmask: 255.255.254.0 (255.255.254.0)
    Default-router: 147.87.175.16 (147.87.175.16)

```

It is often important for the user to look at the functionality of a PROFINET field device without having detailed knowledge about the contents of the description file. This is done by the GSD Checker available at www.profinet.com. The GSD Checker can be used to view GSD files for PROFINET. The GSD checker interprets such a file and is able to check it for correctness. With a simple mouse click, the syntax of a GSD file can be checked:




Figure 68: GSD Checker for displaying the GSD file

With a browser display, the contents of the GSD file can be displayed in a readable and printable form:




Figure 69: Representation in the GSD Checker

Any commercially available XML editor or a normal text editor can be used to create a GSD file. With the functionality "Check" the syntax and part of the sematic is verified and errors and warnings are displayed.




Figure 70: Representation as XML file and result of a check

In this chapter the configuration of a PROFINET IO-System with the CODESYS Engineering Tool (ET) is showed using a Raspberry Pi as a Controller.

First we have to download and install the CODESYS and Raspberry Pi runtime on your development PC

Download and install the free **CODESYS Development System** (<https://store.codesys.com/engineering/codesys.html>).

Download the **CODESYS Control for Raspberry Pi SL** (<https://store.codesys.com/codesys-control-for-raspberry-pi-sl.html>). Without a license this runtime will run for two hours. After two hours a restart is required. For demonstrations and training this is acceptable. A license can always be added later if required.




Figure 71: Select the Packer Manager to add the Raspberry Pi Controller

Open the Package Manager and install the **CODESYS Control for Raspberry Pi SL**.

PROFINET Commander runs as a PROFINET I/O controller (conformance class B, real time – RT) on a PC with an easy to use graphical user interface. With PROFINET Commander, users can test and build a PROFINET network and quickly connect I/O Devices without PLC programming.




Figure 72: Controlling device without PLC programming

Users gain the ability to test and set up a PROFINET IO Device, test wiring (I/O Checking) and/or systems from their PC before putting into production. For developers of PROFINET I/O devices, the added benefit of using the tool is simple testing of their product for correct operation and diagnostic functionality prior to PROFINET certification testing and final product release.

For more information and download the product see [PROFINET Commander](#).

The PROFINET Test Bundle supports the development of PROFINET interfaces for field devices and controllers. It can be used as a means for preparation of the mandatory certification for PROFINET devices. The goal of this test system is to have all the necessary documents and test systems for RT and IRT and Security Level 1 (NetLoad) combined in one bundle with all the electronic test cases to be performed during a certification test.




Figure 73: PROFINET Test Bundle usage

This PROFINET Test Bundle can be downloaded for free for PI Members only at [PROFINET Test Bundle](#).

Wireshark is an open-source programme for recording Ethernet and PROFINET telegrams


With Wireshark every PC is upgraded to a Ethernet analysing device without any additional cost.

Attention: in some enterprises the installation of such a powerful analysing tool is considered as a first step for hacking and requires a special allowance.

Installation of Wireshark

1.Download the latest version of the software for your operating system from the website www.wireshark.org.

2.Install the Wireshark on your PC. Typically the driver for your Ethernet interface is included.

3.Go to coloring rules and replace the color scheme with the one for PROFINET:  [PROFINET IRT Colors Wireshark.ini](#)




Figure 74: Wireshark coloring rules for PROFINET

The Software has the following functions.




Figure 75: Functionalities of Wireshark




Figure 76: Functions of Wireshark

And you see the following windows:

PNIO test 1 - Ethernet

File Edit View Go Capture Analyze Statistics Help

Filter: `ip.addr == 147.74.184.141 || eth.type == 0x8892` Expression... Clear Apply

No.	Time	Source	Destination	Protocol	Info
140	10.106184	Siemens_6b:8b:f6	01:0e:cf:00:00:00	PN-DCCP Ident	Req, Xid:0x1, NameOfStation
287	16.457490	Siemens_6b:8b:f6	01:0e:cf:00:00:00	PN-DCCP Ident	Req, Xid:0x2, NameOfStation
288	16.460026	Siemens_6b:8b:f6	01:0e:cf:00:00:00	PN-DCCP Ident	ok, Xid:0x2, NameOfStation, Dev-Options(5), TypeOfStation, Dev-ID, Dev-Role, IP
319	19.557155	Siemens_6b:f6:23	Siemens_6b:f6:23	PN-DCCP Set	Req, Xid:0x1, IP, End-Trans
320	19.559436	Siemens_6b:f6:23	Siemens_6b:f6:23	PN-DCCP Set	ok, Xid:0x1, Response(ok), Response(ok)
321	19.568160	Siemens_6b:f6:23	Siemens_6b:f6:23	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38400 (Valid,Primary,ok,Run)
322	19.570385	Siemens_6b:f6:23	Siemens_6b:f6:23	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38464 (Valid,Primary,ok,Run)
323	19.571643	Siemens_6b:f6:23	Siemens_6b:f6:23	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38464 (Valid,Primary,ok,Run)
324	19.591280	Siemens_6b:f6:23	Siemens_6b:f6:23	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38784 (Valid,Primary,ok,Run)
329	19.593273	Siemens_6b:f6:23	Siemens_6b:f6:23	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38848 (Valid,Primary,ok,Run)
330	19.595267	Siemens_6b:f6:23	Siemens_6b:f6:23	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38848 (Valid,Primary,ok,Run)
331	19.597266	Siemens_6b:f6:23	Siemens_6b:f6:23	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38912 (Valid,Primary,ok,Run)
332	19.599267	Siemens_6b:f6:23	Siemens_6b:f6:23	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38912 (Valid,Primary,ok,Run)
334	19.601421	Siemens_6b:f6:23	Siemens_6b:f6:23	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38976 (Valid,Primary,ok,Run)
335	19.603161	Siemens_6b:f6:23	Siemens_6b:f6:23	PNIO	RTCL, FrameID: 0xc000, DataLen: 40, Cycle: 9536 (Valid,Primary,ok,Stop)

Display Filter

Sequence of frames in the storage file

Frame 288 (108 bytes on wire, 108 bytes captured)

Ethernet II, Src: 08:00:06:6b:f6:23, Dst: 08:00:06:6b:f6:23

PROFINET acyclic Real-Time, FrameID: 0xffef, DataLen: 92

PROFINET DCP, Ident ok, Xid:0x2, NameOfStation, Dev-Options(5), TypeOfStation, Dev-ID, Dev-Role, IP

Service-ID: Identify (5)

Service-Type: Response Success (1)

Xid: 0x00000002

Reserved: 0

DCPDataLength: 82

Block: Device/NameOfStation, Status: 0, "IM151-3PN"

Padding: 1 byte

Block: Device/Device Options, Status: 0, 5 options

Block: Device/Manufacturer specific, Status: 0, TypeOfStation: "IM151-3"

Block: Device/Device ID, Status: 0, 0x002a/0x0301

Block: Device/Device Role, Status: 0, IO-Device

Block: IP/IP, Status: IP not set, IP: 0.0.0.0, Subnet: 0.0.0.0, Router: 0.0.0.0

The selected frame is decoded

```

0000 08 00 06 6b f6 23 08 00 06 6b f6 23 88 92 fe ff  ...k.... .k.#....
0010 05 01 00 00 00 00 00 00 52 02 02 00 00 00 00  .....R.....
0020 49 4d 31 35 31 2d 33 50 4e 02 05 00 0c 00 00  IM151-3P N.....
0030 01 02 01 02 02 02 03 02 04 02 01 00 0a 00 00  IM151-3. ....*
0040 49 4d 31 35 31 2d 33 00 02 03 00 06 00 00 00  IM151-3. ....*
0050 03 01 02 04 00 04 00 00 01 00 01 02 00 0e 00  .....
0060 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00  .....

```

File: PNIO test 1 548 KB 00:00:26 P: 7164 D: 6779 M: 0

Figure 77: Display of Wireshark

If you use the PROFINET colors the cyclic data will be green.

PNIO test 1 - Ethernet

File Edit View Go Capture Analyze Statistics Help

Filter: `ip.addr == 147.74.184.141 || eth.type == 0x8892` Expression... Clear Apply

No.	Time	Source	Destination	Protocol	Info
319	19.557155	147.87.174.141	147.87.174.142	PN-DCCP	Set Req, Xid:0x1, IP, End-Trans
320	19.559436	147.87.174.142	147.87.174.141	PN-DCCP	Set ok, Xid:0x1, Response(ok), Response(ok)
321	19.568160	147.87.174.141	Broadcast	ARP	who has 147.87.174.142? Tell 147.87.174.141
322	19.570385	147.87.174.142	147.87.174.141	ARP	147.87.174.142 is at 08:00:06:6b:f6:23
323	19.571643	147.87.174.141	147.87.174.142	PNIO-CM	Connect request, ARBlockReq, IOCRBlockReq, IOCRBlockReq, ... (10 blocks)
324	19.583391	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38400 (Valid,Primary,ok,Run)
325	19.585304	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38464 (Valid,Primary,ok,Run)
326	19.587280	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38528 (Valid,Primary,ok,Run)
327	19.589263	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38592 (Valid,Primary,ok,Run)
328	19.591280	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38656 (Valid,Primary,ok,Run)
329	19.593273	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38720 (Valid,Primary,ok,Run)
330	19.595267	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38784 (Valid,Primary,ok,Run)
331	19.597266	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38848 (Valid,Primary,ok,Run)
332	19.599267	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38912 (Valid,Primary,ok,Run)
333	19.601246	147.87.174.142	147.87.174.141	PNIO-CM	Connect response, OK, ARBlockRes, IOCRBlockRes, IOCRBlockRes, ... (5 blocks)
334	19.601421	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38976 (Valid,Primary,ok,Run)
335	19.603161	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 39040 (Valid,Primary,ok,Run)
336	19.603270	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 39040 (Valid,Primary,ok,Run)
337	19.603324	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 39104 (Valid,Primary,ok,Run)
338	19.605271	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 39104 (Valid,Primary,ok,Run)
339	19.607275	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 39168 (Valid,Primary,ok,Run)
340	19.607268	147.87.174.142	147.87.174.141	PNIO	RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 39168 (Valid,Primary,ok,Run)

Frame 324 (60 bytes on wire, 60 bytes captured)

Ethernet II, Src: 08:00:06:6b:f6:23, Dst: 08:00:06:6b:f6:23

PROFINET cyclic Real-time, RTCL, FrameID: 0xc080, DataLen: 40, Cycle: 38400 (Valid,Primary,ok,Run)

PROFINET IO Cyclic Service Data Unit: 40 bytes

```

UUUU 08 00 06 6b f6 23 08 00 06 6b f6 23 88 92 c0 80  ...K.... .K.#....
0010 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00  .....
0020 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00  .....
0030 00 00 00 00 00 00 00 00 96 00 35 00 00 00 00  .....

```

File: PNIO test 1 548 KB 00:00:26 P: 7164 D: 7164 M: 0

Figure 78: Frames are colored according the PROFINET Manual

Display and capture filters have not the same syntax!

- Only PROFINET frames:

pn_rt (same as eth.type == 0x8892)

- Only frames related with the PROFINET IO protocol

pn_io (does not include e.g. the DCP protocol)

- All PROFINET frames

pn_rt or pn_io




Figure 79: Display filter of the PROFINET protocols

More specific filters can be set by selecting the protocol element.




Figure 80: Simple definition of display filters